

# Jewelry and Metals Studio

Acetylene/Air Torch



Member Name: \_\_\_\_\_

## Torch ON Procedure

- Turn on vent hood
- Turn tank on (half turn only, counter-clockwise)
- Set regulator to proper pressure (just shy of 15 psi, clockwise)
- Light torch

## Torch OFF Procedure

- Turn tank off (clockwise)
- Bleed gas off torch handle
- Release pressure on regulator (counter-clockwise)
- Turn off vent hood

## Torch Clean Up

- Hang up hose and torch handle
- Clean off soldering area (flux, solder, water, bricks, rocks, pins, etc.)

Instructor Signature: \_\_\_\_\_

Member is certified

Member needs to retest/retake class